IMPORTANT SAFETY INSTRUCTIONS

WHEN USING AN ELECTRICAL FURNISHING, BASIC PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

READ ALL INSTRUCTIONS BEFORE USING THIS FURNISHING

DANGER – TO REDUCE THE RISK OF ELECTRIC SHOCK: ALWAYS UNPLUG THIS FURNISHING FROM THE ELECTRICAL OUTLET BEFORE CLEANING.

WARNING – TO REDUCE THE RISK OF BURNS, FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS:

1. Unplug from outlet before putting on or taking off parts.

2. Close supervision is necessary when this furnishing is used by or near children, invalids, or disabled persons.

3. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

4. **Never operate this furnishing if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the furnishing to a service center for examination and repair.**

5. Keep the cord away from heated surfaces.

6. Never operate the furnishing with the air openings blocked. Keep the air openings free of lint, hair, and the like.

7. Never drop or insert any object into any opening.

8. Do not use outdoors.

9. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.

10. To disconnect, turn all controls to the OFF position, then remove plug from outlet.

11. Do not leave furnishing unattended when it is plugged in.

12. Be sure mirror is not in a position where it can reflect sunlight; reflected sunlight can cause fire.

13. Do not use on a soft surface, such as a bed, where openings may be blocked.

14. Turn switch to OFF position, allow unit to cool and unplug cord before replacing light bulbs.

15. Do not place or store furnishing where it can fall or be pulled into a tub or sink.

16. If furnishing falls into water, unplug it immediately. **Do not reach into the water.**

17. To protect against electrical hazards, do not use while bathing or in the shower.

18. Never use while sleeping.

19. Do not use a bulb greater than 20 watts.

Use on any 120 volt 60 hertz AC electric outlet (ordinary house current). Do not use it in any other electrical outlet.

FOR HOUSEHOLD USE ONLY

SAVE THESE INSTRUCTIONS

OPERATING INSTRUCTIONS

To reduce the risk of electric shock, this mirror has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Never use with an extension cord unless plug can be fully inserted. Do not change the plug in any way.

CAUTION: BE SURE DIRECT SUNLIGHT DOES NOT STRIKE MIRROR WHEN LEFT UNATTENDED; REFLECTED SUNLIGHT CAN CAUSE FIRE.

1. Your lighted makeup mirror will rotate 360° so that you can use either the normal view or the 7x magnification view located on the opposite side.

2. Plug cord into any standard 120 volt wall outlet. To turn on light, simply turn the switch on the line cord to ON setting.

3. After use, always turn switch to the OFF position.

4. The beauty and design of this mirror complement any decor. Therefore, you may wish to leave the mirror displayed. However, if you choose to store the mirror, see section about storage for detailed information.

TO REPLACE BULB

CAUTION: TURN OFF POWER AND UNPLUG. ALLOW TO COOL AT LEAST 3 MINUTES BEFORE REPLACING BULB.

Contact a Conair Service Center at 1-800-3-CONAIR for replacement bulb information (ask for replacement bulb RP-BE151T. Bulbs are $1.50 each; includes shipping and handling).

1. Remove the two screws located on each side of the mirror. (Fig. 1).

2. Carefully lift off the removable housing from the half that is affixed to the stand.

3. Unscrew the old bulb and replace with new bulb. (Fig. 2)

4. Carefully replace the removable half after aligning the screw holes to the fixed half.

5. Insert screws into screw holes and tighten.



Figure 1



Figure 2

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

CAUTION: RISK OF FIRE; USE ONLY 20 WATTS MAXIMUM 120 VOLT; TYPE T BULBS.

DISCONNECT FROM THE SUPPLY CIRCUIT BEFORE SERVICING OR CLEANING.

DO NOT SUBMERSE.

MODEL: BE151SNK

RATING: 120V AC 60Hz 20W

DATE CODE:

STORAGE

Disconnect from electrical outlet. BE SURE DIRECT SUNLIGHT DOES NOT STRIKE MIRROR WHEN LEFT UNATTENDED. Allow to cool to room temperature before storing. Place in cool, dry area out of reach of children, where mirror will not be damaged.

MAINTENANCE

Your lighted mirror is designed for household use and is virtually maintenance free. No lubrication is needed.

If cleaning becomes necessary, disconnect the furnishing from the power source, allow it to cool and wipe exterior with a damp cloth. Clean mirror surfaces with a glass cleaner. Do not light until you are certain mirror is completely dry. If any abnormal condition occurs, unplug the lighted mirror, allow it to cool, and return it to an authorized service center for repair.

Handle cord carefully to prolong its life; do not jerk or strain at plug connections, or wrap cord around mirror for storage. This could cause damage to the cord or a short circuit. To store mirror, coil cord loosely.

WARNING:
IF YOU THINK THE POWER IS OFF WHEN THE SWITCH IS OFF, YOU'RE WRONG.

KEEP AWAY FROM WATER



Everybody knows that electricity and water are a dangerous combination. But did you know that an electrical furnishing is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your furnishings, keep them unplugged.

ALWAYS UNPLUG SMALL FURNISHINGS

LIMITED ONE YEAR WARRANTY

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the furnishing is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed below, together with your purchase receipt and $3.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

Please register this product at:
www.conair.com/registration.

For info on any Conair product call: 1-800-3-CONAIR
or visit us on the web at: www.conair.com

Service Center
Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307

©2013 Conair Corporation
Model BE151SNK
13PM142875

IB-12251

true glow

Soft halo lighting for a
gentle glow.

CONAIR®

Model BE151SNK